

Tonly vehicle safety operation regulations

Improper handling of dump trucks is dangerous and accidents are possible. The best way to prevent accidents is to follow the rules of safe operation.

Forbidden items during driving operation

- 1) Fatigue driving, driving with sick vehicles.
- 2) The hand signals between the driver and the commander are not clear.
- 3) Operate the vehicle in loose clothing.
- 4) Carelessness checking the state of the vehicle before driving.
- 5) Driving without paying attention to the external operating environment.
- 6) Don't follow the instructions.
- 7) Incorrect operation of vehicle.
- 8) The vehicle is not maintained.
- 9) When the cargo is fully loaded, it is strictly prohibited to go downhill at a high speed or stop vehicles suddenly.

Safe operation rules for container lifting and falling

- 1) When the container is lifted, the operator must not leave the operating position.
- 2) Do not allow any person to stand or walk near the work area while the container is being lifted or in the lifting state.
- 3) Never stand under a lifted box until the container is fully supported for vehicle maintenance.

Safe operation rules for loading and unloading

- 1) The loading goods should be equally distributed in the compartment to ensure that the goods are equally loaded on the front, behind, left and right of the container, and to minimize the height of the loaded goods.
- 2) When using loader or electric shovel, avoid the collision with the container, the load of goods should be perpendicular to fall on the container central, loading large pieces of gravel and other goods should be more careful to prevent damage to the bottom of the container. Do not fall from a high place.
- 3) Do not unloading the goods when the ground conditions in the dumping area are not clear.
- 4) Container lifting and dumping of materials should never be carried out under any circumstances where the vehicle is likely to tip over.
- 5) When unloading the materials, ensure that the vehicle of the front, behind, left and right of ground is firm flat, keep the level of the vehicle; Do not lift in the downhill.